

Dexterity

## **TECHNICAL SHEET**

soapy water and let it dry at room temperature. An adequate lens cleaning cloth can also be used. Do not use petrol, chlorinated degreasers, organic solvents or abrasive detergents for cleaning the parts of the equipment.

The product can be disinfected regularly using

alcohol or disinfectant liquid.

Storage and cleaning

Sir Safety System S.p.A. Single-member company Wholly-owned subsidiary of Sir Holding Srl Via dei Fornaciai, 9 - Santa Maria degli Angeli 06081 Assisi - Perugia - Italy Tel.+39 075.8043737 - Fax +39 075.8048686 VAT Nr. IT 03359340548 Viale Europa 74 20090 Cusago Milano Tel. +39 02.90394575 Fax +39 02.90394441 export@sirsafety.com www.sirsafety.com





Name: SCHERMO M-5100		Code: FB1148	FB11 FACE SHIELDS
These products are damage to the eyes The product has be	ET lenses (protection against liquid splans or to eyesight.  en designed and manufactured to 6/425 and subsequent amendments.	shes that may cause o comply with	a speld
Category	Colours		Available Sizes U
Quantity/Carton	EC Standards EN 166  Optical Class:1 Field of use:3		Important Information Use only as a face protection shield to avoid liquid splashes.  Keep in a cool, dry place, away from heat sources and direct light.  Before each use, make sure the equipment is in perfect conditions and replace it in case of any damage.  The equipment must becleaned after each use. Clean the product using a damp cloth with warm