

Sir Safety System S.p.A. Single-member company Wholly-owned subsidiary of Sir Holding Srl Via dei Fornaciai, 9 - Santa Maria degli Angeli 06081 Assisi - Perugia - Italy Tel.+39 075.8043737 - Fax +39 075.8048686 VAT Nr. IT 03359340548 Viale Europa 74 20090 Cusago Milano Tel. +39 02.90394575 Fax +39 02.90394441

TECHNICAL SHEET

export@sirsafety.com www.sirsafety.com





Name: STRATO helmet red

Code: FD2160

FD21 FALL ARREST DEVICES - PETZL

Description

Helmet made of ABS, EPP, EPS, polyamide, polycarbonate, high-strength polyester, polyethylene.

Equipped with a DUAL chinstrap that allows the worker to modify the strength of the chinstrap to adapt the helmet to different environments: work at height or work on the ground. The closed outer shell protects against electrical hazards, projection of molten metal and flames. Shock absorptionoccurs by deformation of the expanded polystyrene inner

shell.

The CenterFit adjustment system adjusts the headband to centre the helmet well on the head and for better stability.

Headband: 53-63 cm

Weight: 350 g.

The case is equipped with:

- Side slots for mounting noise protectors.

- Inserts to accommodate a protective visor.

- Slot for mounting a headlamp.

- Four positioning hooks for mounting a headlamp with elastic headband.

Equipped with resistance to lateral deformation LD and molten metal splash MM, electrical insulation 440V a.c. and resistance to low temperatures down to $-H \in \mathbb{R}$.

The product has been designed and manufactured tocomply with Regulation

(EU) 2016/425 and subsequent amendments.

Category	Colours	Available Sizes
Ш		Made to order: U In stock:
Quantity/Carton	EC Standards	Important Information
1	EN 397	To be used in conjunction with the other work- positioning devices in confined spaces.
	EN 12492	Read carefully the user sheet included.
		Make sure the item is in good condition, undamaged before use. Once you become aware
	EN 50365	of a damage, you should immediately replace it.
		Keep in a cool dry place, far from heat sources.
		Clean the shell with warm soapy water, then rinse with clear water. Do not use any solvents.
Dexterity		Storage and cleaning

